



# Umschlüsselung Gehäuselager

## Ball Bearing Units transcoding

<b>EBS</b>	<b>INA</b>	<b>SNR</b>
UCEF	RCJY	UCFE
UCEFC	RMEY	UCFCE
UCEFL	RCJTY	UCFLE
UCEFLZ	RCJTZY	UCFLZ
UCEP	RASEY	UCPE
UCESF	RCFY	–
UKEF	–	UKFE
UKEFC	–	UKFCE
UKEFL	–	UKFLE
UKEFLZ	–	UKFLZ
UKEP	–	UKPE
UKESF	–	–
SBEF	PCJY	USFE
SBEFC	PMEY	USFCE
SBEFL	PCJTY	USFLE
SBEFLZ	PCJTZY	USFLZ
SBEP	PASEY	USPE
SBESF	PCFY	–
SAEF	PCJ	ESFE
SAEFC	PME	ESFCE
SAEFL	PCJT	ESFLE
SAEFLZ	PCJTZ	ESFLZ
SAEP	PASE	ESPE
SAESF	PCF	–
HCEF	RCJ	EXFE
HCEFC	RME	EXFCE
HCEFL	RCJT	EXFLE
HCEFLZ	RCJTZ	EXFLZ
HCEP	RASE	EXPE
HCESF	RCF	–
CSEF	–	–
CSEFC	–	–
CSEFL	–	–
CSEFLZ	–	–
CSEP	–	–
CSESF	–	–